



# BOOMPPODS™

music . anywhere . everywhere



User Manual




## doubleblaster

BOOMPPODS™ designed in the UK by DT-Design Ltd. All rights reserved ©2014. This product uses BOOMPPODS™ technology and is covered by international patents, doubleblaster - IP: 201230133254.2



### Introduction:

Before using your doubleblaster speaker for the first time, please take a few moments to read through the user manual.




1. Power on/off 2. Micro USB charging port 3. LED indicator 4. Subwoofer 5. Speaker

### Bluetooth operation:

When using with Bluetooth for the first time, please pair the speaker with your mobile phone as follows:

1. Activate your phone's Bluetooth function and then enter its searching mode.
2. To switch on your doubleblaster speaker, push the on/off button (1) to "on", this will activate the Bluetooth function.
3. The LED (3) will flash alternately red and blue and a beep will indicate that the Bluetooth function has been successfully activated.
4. Your mobile phone will automatically find a new Bluetooth device called "DOUBLEBLASTER". Connect this device and a beep will indicate that the speaker has successfully been connected.
5. Please adjust the sound to a moderate volume and enjoy the music.
6. To switch off your doubleblaster speaker, push the on/off button (1) to "off".



### Wired operation:

You can use your doubleblaster as a wired speaker to increase battery life. Simply connect the 3.5mm line-in cable to your audio source and the Micro USB end to your doubleblaster speaker (2).

### Charging:

To charge, simply connect the USB cable end directly to a PC, laptop or mains USB charger and the Micro USB end to your doubleblaster speaker (2). The LED (3) on your speaker will turn red whilst charging, and turn off when fully charged. Please note that the speaker **will not** charge and play at the same time

### Package contents:

- 1x doubleblaster wireless portable bass speaker
- 1x Micro USB charging, 3.5mm audio and standard USB cable
- 1x travel bag
- 1x user manual

### Technical details:

- 1 x 3W & passive subwoofer
- Battery capacity: 1000mAh 3.7V
- Frequency: 120Hz-15000Hz
- Charge time: 2.5 hours
- Bluetooth range: 10m (open space)
- Bluetooth: 3.0

### General guidelines:

- Keep away from high temperature or prolonged exposure to direct sunlight.
- Avoid contact with liquids.
- Do not insert any conductive objects into the sound box.
- Do not disassemble.
- Do not drop the product.
- Keep out of reach of children.

### Warranty:

Your BOOMPPODS™ product is guaranteed against any defects in material or workmanship for one full year from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage such as a knock or immersion in water, etc.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

Please check [www.boompods.com](http://www.boompods.com) for your local service centre.

BOOMPPODS™  
[www.boompods.com](http://www.boompods.com)